

# PID Tuning Rubric — MARS Hexapod v2.0

Target: Teensy 4.1 controller with sparse-feedback PID per joint, estimator-based error, dt-aware PID, and shadow mode (`pid.mode=shadow`).

## 1. Preparation

**Goal:** Create a repeatable, safe environment for tuning.

### 1. Firmware/config setup

- Ensure firmware has:
  - Estimator + filtered D enabled.
  - dt-aware PID (uses loop dt from `LoopTimer`).
- In `/config.txt` (or via PID commands), set:
  - `pid.enabled=false`
  - `pid.mode=shadow`
  - `pid.kp_milli.<coxa|femur|tibia>=0`
  - `pid.ki_milli.<coxa|femur|tibia>=0`
  - `pid.kd_milli.<coxa|femur|tibia>=0`
  - `pid.kd_alpha_milli.<coxa|femur|tibia>=200`
  - `pid.shadow_report_hz=2` (or a modest value 1–5 Hz)

### 2. Operating scenario

- Use a simple, repeatable motion:
  - **Static stance:** STAND at a neutral pose; or
  - **Slow tripod gait:** MODE TEST with conservative parameters.
- Disable or throttle SD logging to avoid timing interference while tuning.

### 3. Safety checks

- Confirm:
    - `safety.soft_limits=true`
    - `safety.collission=true`
    - Over-temp lockout behaves as expected.
  - Keep an emergency DISABLE handy during active-mode tests.
- 

## 2. Baseline (PID Off)

**Objective:** Understand the controller behavior without PID corrections.

### 1. Configuration

- PID DISABLE
- PID MODE SHADOW
- Keep K gains at 0 (P/I/D all zero).

### 2. Observe

- PID\_SHADOW lines:
  - With PID off, `diff_cd` should be ~0 (PID and base targets match).

- **STATUS [TIMING]:**
  - Ensure tick time and jitter are comfortably below the 6.024 ms budget.
- **Physical behavior:**
  - Evaluate how stiff/sloppy the legs feel under STAND or slow TEST gait.

This provides the reference you're trying to improve upon with PID.

---

### 3. Tune P (Proportional) Only

**Objective:** Increase stiffness and responsiveness without inducing oscillation.

1. **Enable PID with P only**
  - PID ENABLE
  - Set Kp:
    - Start small per joint group:
      - \* Coxa: PID KP COXA 100–200 (milli)
      - \* Femur: PID KP FEMUR 200–400
      - \* Tibia: PID KP TIBIA 200–400
    - Or use PID KP ALL <value> if you want a uniform starting point.
  - Keep:
    - PID KI ... 0
    - PID KD ... 0
2. **Stay in shadow mode initially**
  - PID MODE SHADOW
  - Monitor PID\_SHADOW:
    - `err_cd` (target - estimate) per leg/joint.
    - `diff_cd` (pid - base) per leg/joint.
3. **Interpretation rubric for P**
  - **Too low Kp**
    - `diff_cd` small.
    - Errors decay slowly; behavior close to baseline.
  - **Good Kp**
    - `diff_cd` moderate and roughly proportional to `err_cd`.
    - In shadow mode, corrections look sensible (no wild sign flips).
  - **Too high Kp**
    - `diff_cd` large; may alternate sign rapidly.
    - Indicates potential overshoot/oscillation if applied.
4. **Active-mode test**
  - Once shadow behavior looks reasonable:
    - PID MODE ACTIVE
  - Evaluate:
    - Leg stiffness increases appropriately.

- No high-frequency buzzing or visible oscillation.
- `STATUS [TIMING]` remains within budget.

**Rule of thumb:** Increase `Kp` until you see the first sign of oscillation in shadow mode, then reduce `Kp` by about 30–50%.

---

## 4. Add D (Derivative) for Damping

**Objective:** Reduce overshoot and damp oscillations introduced by P.

- Initial D settings**
  - With `Kp` fixed from the previous step:
    - Coxa: `PID KD COXA 50–100`
    - Femur: `PID KD FEMUR 100–200`
    - Tibia: `PID KD TIBIA 100–200`
  - Derivative smoothing:
    - `PID KDALPHA ALL 200` (0..1000; higher = faster tracking, lower = more smoothing).
- Tune in shadow mode**
  - `PID MODE SHADOW`
  - For small steps or gait transitions, observe:
    - `diff_cd` behavior around direction changes.
    - D should:
      - \* Reduce overshoot in the hypothetical PID target.
      - \* Make `diff_cd` less “spiky”.
- Adjustments**
  - If `diff_cd` looks noisy:
    - Lower (e.g., 150 or 100) for more smoothing; or reduce KD.
  - If response feels sluggish in shadow:
    - Slightly raise KD or increase .
- Active-mode verification**
  - `PID MODE ACTIVE`
  - Check:
    - Movements are smooth with less overshoot.
    - No “ringing” after leg motions.
    - Timing remains within limits.

**Rubric:** - **Too little D:** overshoot and ringing after movements. - **Good D:** crisp motion, minimal overshoot, quick settling. - **Too much D:** sluggish response; legs resist motion too strongly and correct slowly.

---

## 5. Add I (Integral) for Steady-State Accuracy

**Objective:** Remove persistent steady-state error (e.g., gravity sag).

1. **Start very conservatively**
  - With Kp and Kd tuned:
    - Set KI small:
      - \* Coxa: PID KI COXA 0–10
      - \* Femur: PID KI FEMUR 10–30
      - \* Tibia: PID KI TIBIA 10–30
2. **Static test (STAND)**
  - Let the robot stand in a neutral pose for several seconds.
  - Observe:
    - Does the leg settle closer to the commanded angles?
    - Does `diff_cd` drift slowly in a direction that reduces `err_cd`?
3. **Watch for integral windup behavior**
  - Signs of too much I:
    - Slow, large-amplitude oscillations in joint angles.
    - `diff_cd` continues to grow even when `err_cd` is small or reversed.
  - Mitigation:
    - Reduce KI.
    - Confirm integral clamps are effective (no runaway).

**Rubric:** - **No I (KI=0):** steady-state error remains (leg sags a bit). - **Good I:** error diminishes near zero without introducing slow oscillations. - **Too much I:** system “hunts” around the target with slow big swings.

---

## 6. Scenario Validation

Run through multiple scenarios with final candidate gains:

1. **Static stance**
  - STAND:
    - Legs hold position with minimal drift.
    - No visible jitter or micro-oscillations.
2. **Slow tripod gait**
  - MODE TEST:
    - Smooth transitions between stance and swing.
    - No jerk at lift/landing.
    - STATUS [TIMING] shows no persistent overruns.
3. **Disturbance test**
  - While in STAND, gently push the body or a tibia:
    - Robot should resist and return smoothly to target.
    - Response should be firm but not violently stiff.
4. **Temperature / logging check**
  - Ensure PID behavior remains stable under:
    - Logging enabled at realistic rates.
    - Extended runtime (thermal conditions).

---

## 7. Finalization and Documentation

### 1. Persist tuned gains

- Use PID commands that update `/config.txt`:
  - PID KP ...
  - PID KI ...
  - PID KD ...
  - PID KDALPHA ...
- Confirm `/config.txt` reflects your tuned values on reboot.

### 2. Record a snapshot

- Save:
  - Tuned Kp/Ki/Kd/kd\_alpha per joint.
  - Representative STATUS [TIMING] output.
  - Sample PID\_SHADOW lines for:
    - \* STAND
    - \* TEST gait
- Optionally store notes in `docs/PROJECT_SPEC.md` or a dedicated tuning document.

### 3. Operational defaults

- Decide:
    - Normal operating mode (`pid.mode=active` or `shadow` for further validation).
    - Default `pid.enabled` at boot (probably `false` until PID is fully vetted on hardware).
- 

## Quick Reference (Starting Gains)

These are only **starting points**; tune using the rubric above:

- **Coxa**
  - Kp 100–200
  - Ki 0–10
  - Kd 50–100
- **Femur**
  - Kp 200–400
  - Ki 10–30
  - Kd 100–200
- **Tibia**
  - Kp 200–400
  - Ki 10–30
  - Kd 100–200
- **Derivative smoothing**
  - `kd_alpha_milli` 200 as a starting point.